

ELLISON STUDIOS.

Product Care & Assembly Guide

Congratulations on your purchase of your ELLISON STUDIOS. Earth Dining Table. This document lists the contents included in your delivery.

Please take the time to read this document, as it includes important information about caring for your product as well as any assembly instructions that might be required. As you unpack your new item, place the contents on a carpeted or padded area to protect them from damage before placing the product in its final position.

EARTH DINING TABLE

Hardware

16 x 1/4x20mm bolt screws

Tools Required


Allen Key

People Required

2 People

Estimated Time of Assembly

30 Minutes



Contact Us

For Australian warranty related queries please contact:

customerservice@ellisonstudios.com

For any international customer service inquiries please contact the retailer of purchase.


Ellison Studios Group Pty Ltd

ELLISON STUDIOS.

Step 1


Place the table top face down onto a clean, flat, surface (we recommend using a towel or sheet underneath for protection).

Arrange the legs on the underside of the table and fasten each of the bolts provided into the table using the provided allen key.



Step 2

Carefully turn the table over (2 persons are recommended). When lifting and flipping your table to be the correct way up, do not use the legs as a tilting point. Their connection to the table top is not designed to be a leverage point and the level of load through this joint may cause the legs to be damaged or break. It is our recommendation that you check and tighten all screws every 6 months.



Care Instructions

Ensure the longevity and appearance of your ELLISON STUDIOS. timber veneered and solid timber furniture with these care instructions:

Regular Dusting: Use a soft, dry cloth regularly to prevent the build-up of dirt and grime.

Cleaning: Clean with a damp cloth and mild soap solution, wiping in the direction of the wood grain. Avoid excessive water. Recommended products are available in the ELLISON STUDIOS. online store.

Avoid Direct Sunlight: Position furniture away from windows or use curtains to prevent fading and discoloration.

Temperature and Humidity: Maintain a stable environment to avoid warping or cracking.

Spills and Stains: Blot spills immediately with a clean, dry cloth. Consult specific care instructions for tougher stains.

Protective Measures: Use coasters, placemats, and felt pads to prevent damage from heat, spills, and scratches.

Polishing: Periodically polish with recommended products from the ELLISON STUDIOS. online store.

Avoid Harsh Chemicals: Refrain from using abrasive cleaners or harsh chemicals.

Maintenance: Regularly check and tighten hardware or joints, and ensure moving parts operate smoothly.

Following these simple steps and guidelines will help to ensure the longevity of your ELLISON STUDIOS. product.

ELLISON STUDIOS.