

ELLISON STUDIOS.

Product Care & Assembly Guide

Congratulations on your purchase of your ELLISON STUDIOS. Yoko Bed. This document lists the contents included in your delivery.

Please take the time to read this document, as it includes important information about caring for your product as well as any assembly instructions that might be required. As you unpack your new item, place the contents on a carpeted or padded area to protect them from damage before placing the product in its final position.

YOKO BED

Hardware

- 2 x 20x100x50mm wooden dowel
- 2 x Ø10x30mm dowel
- 4 x 5/16x65mm bolt screws
- 4 x 8xØ19mm washer
- 4 x Ø8mm spring washer
- 16 x 5/16x25mm bolt screws
- 2 x Ø20x80mm dowel
- 8 x M10x100mm bolt screws
- 8 x 10xØ23mm washer
- 8 x 10 spring washer

Tools Required


- Allen Key
- Hex head key

People Required

2 People

Estimated Time of Assembly

1 Hour



Contact Us

For Australian warranty related queries please contact:

customerservice@ellisonstudios.com


For any international customer service inquiries please contact the retailer of purchase.

Ellison Studios Group Pty Ltd

ELLISON STUDIOS.


Step 1

Lay both bed frame pieces face down onto a clean, flat surface (we recommend using a towel or sheet underneath for protection). Using the 2 x 20x100x50mm wooden dowel blocks and the 2 x Ø10x30mm dowels, connect the frames by pushing the two halves together evenly as shown below.



Step 2


Use each of the 4 x 5/16x65mm bolts to fasten the two frame halves together along the centre join, placing washers and spring washers between the bolt head and the frame as shown below.



ELLISON STUDIOS.


Step 3

Align the Ball Feet and centre support leg with the corresponding holes on the Bed Frames as shown. Fasten the Ball Feet and the centre support leg to the bed frame using the 16 x 5/16x25mm bolt screws and allen key. With a second person to assist you, carefully turn the assembly over so that it is now standing on the ball feet. Make sure to lift the assembled frame rather than use the legs as a tipping point.



Step 4


Using the 2 x Ø20x80mm wooden dowels, slot the headboard in place on top of the base frame. Do not leave the headboard freestanding, hold in place while completing step 5.



ELLISON STUDIOS.

Step 5

Use each of the 8 x M10x100mm bolt screws and hex head key to fasten the headboard to the base frame, placing washers and spring washers between the bolt head and the frame as shown below. The assembly is now complete and product is ready for use.



Care Instructions

Ensure the longevity and appearance of your ELLISON STUDIOS. timber veneered and solid timber furniture with these care instructions:

Regular Dusting: Use a soft, dry cloth regularly to prevent the build-up of dirt and grime.

Cleaning: Clean with a damp cloth and mild soap solution, wiping in the direction of the wood grain. Avoid excessive water. Recommended products are available in the ELLISON STUDIOS online store.

Avoid Direct Sunlight: Position furniture away from windows or use curtains to prevent fading and discoloration.

Temperature and Humidity: Maintain a stable environment to avoid warping or cracking.

Spills and Stains: Blot spills immediately with a clean, dry cloth. Consult specific care instructions for tougher stains.

Protective Measures: Use coasters, placemats, and felt pads to prevent damage from heat, spills, and scratches.

Polishing: Periodically polish with recommended products from the ELLISON STUDIOS online store.

Avoid Harsh Chemicals: Refrain from using abrasive cleaners or harsh chemicals.

Maintenance: Regularly check and tighten hardware or joints, and ensure moving parts operate smoothly.

Following these simple steps and guidelines will help to ensure the longevity of your ELLISON STUDIOS. product.

ELLISON STUDIOS.