

Care Instructions

Ensure the longevity and appearance of your ELLISON STUDIOS. timber furniture with these care instructions:

- Use a soft, dry cloth regularly to prevent the build-up of dirt and grime.
- Clean with a damp cloth and mild soap solution, wiping in the direction of the wood grain. Avoid excessive water. Recommended products are available in the ELLISON STUDIOS. online store.
- Position furniture away from windows or use curtains to prevent fading and discoloration.
- Maintain a stable environment to avoid warping or cracking.
- Blot spills immediately with a clean, dry cloth. Consult specific care instructions for tougher stains.
- Periodically polish with recommended products from the ELLISON STUDIOS. online store.
- Refrain from using abrasive cleaners or harsh chemicals.
- Do not place excessive weight on drawers or shelves. Overloading may affect the performance and longevity of the hardware and structure.
- Open and close drawers gently. Avoid slamming drawers to help maintain smooth operation and reduce wear on hardware.

Following these simple steps and guidelines will help to ensure the longevity of your ELLISON STUDIOS. product.

ELLISON STUDIOS.

ELLISON STUDIOS.

Product Care & Assembly Guide


Congratulations on your purchase of your ELLISON STUDIOS. Notte Dresser. This document lists the contents included in your delivery.

Please take the time to read this document, as it includes important information about caring for your product as well as any assembly instructions that might be required. As you unpack your new item, place the contents on a carpeted or padded area to protect them from damage before placing the product in its final position.

NOTTE DRESSER

Hardware

- | | |
|------------------|----|
| A. Wall Lanyard | x2 |
| B. M4x15mm Screw | x4 |
| C. M4 Washer | x4 |
| D. Wall Anchor | x2 |



Tools Required

Screwdriver (Not Supplied)

Assembly Guidance

2 Person Minimum | 10 Minute Assembly


Contact Us

For Australian warranty related queries please contact:
customerservice@ellisonstudios.com
For any international customer service inquires please contact the retailer of purchase.
Ellison Studios Group Pty Ltd

ELLISON STUDIOS.

Step 1


We strongly recommend that a professional install the provided anti-tip kit to prevent the unit from accidentally falling and causing injury or damage. With a screw driver, secure the anti-tip kit to the unit by screwing the screws (B) and washers (C) into the pre-drilled pilot holes on the rear of the unit.



Step 2

Warning: We strongly recommend that a professional do this step.

Position the console in the final desired position. Drill a pilot hole onto the wall and insert the wall anchor (D) into the pilot hole. Then fasten the lanyard (A) using screw (B) and washer (C) into the wall anchor (D) as shown in the diagram below.



Blank Page