

# SARAH ELLISON.

---

## EARTH OUTDOOR ROUND DINING TABLE ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Sarah Ellison Earth Outdoor Round Dining Table. This document lists the contents included in your delivery. Please take the time to identify the hardware, as well as the individual components of this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

---

### HARDWARE

- 16x Allen Bolt 20mm (H-1)
- 5x Allen Bolt 25mm (H-2)
- 21x Flat Washer (H-3)
- 21x Spring Washer (H-4)
- 16x Dome Nut (H-5)
- 1x Cross Mounting Plate (H-6)

### TOOLS REQUIRED


- 4mm Allen Key L (T-1)

### PEOPLE REQUIRED FOR ASSEMBLY

A minimum of three people are required to assemble this product

### ESTIMATED TIME OF ASSEMBLY

30 mins



---

### CUSTOMER SERVICE


For Australian customer service contact: [info@sarahellison.com.au](mailto:info@sarahellison.com.au)  
For any international customer service inquiries please contact the retailer of purchase

# SARAH ELLISON.

---


## STEP 1

Open box carefully, ensuring the blade of the knife does not come into contact with the product. Remove packaging and lift the product up out of box and gently place on ground.



## STEP 2

Pull out all four legs out of the boxes. Please note that Metal Mounting Plates are pre-assembled to the concrete legs. Carefully check that connections are tight. If needed, re-tighten Metal Mounting Plate with leg using Allen Key (T-1).




# SARAH ELLISON.

---


## STEP 3

Position all four legs upright so as to put down Cross Mounting Plate (H-6) on top of all four pre-assembled square plates. Check holes alignment and attach square plates to Cross Mounting Plate using Allen Bolts (H-1), Spring Washers (H-4), Flat Washers (H-3) and Dome Nuts (H-5). Tighten with Allen Key (T-1) and Wrench. Due to the heavy weight of the product we recommend positioning the leg frame assembly in the final location



## STEP 4


With three people, lift tabletop upright and put it gently down on top of cross mounting plate. Tabletop's underneath surface has a recessed cross pattern to help position tabletop so that holes are aligned with insert nuts.



# SARAH ELLISON.


## STEP 5

When all the holes are aligned, secure the Cross Mounting Plate to the tabletop using Allen Bolts (H-2), Spring Washers (H-4) and Flat Washers (H-3). Engage all bolts by hand first, then fully tighten them using Allen Key (T-1).



## STEP 6

Re-Position in your room by lifting the whole unit only –to avoid damage to your table do not drag it in position, and don't forget to recycle the packaging where possible. If the table needs to be relocated please disassemble by reversing the assembly steps and reassemble in new location



# SARAH ELLISON.

---

## CARE INSTRUCTIONS

With a little care you can prolong the life of your furniture. The following information is only intended as a general guideline. Please follow the instructions to ensure maximum longevity of your Sarah Ellison furniture.

- Dust often using a clean, soft, dry and lint-free cloth.
- When blot spills, wipe with a clean, damp cloth immediately.
- We do not recommend the use of chemical cleansers, abrasives or furniture polish on our waxed finish.
- Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.